


TDAQ design: from test beam to medium size experiments






How do we go



Basic DAQ: De-randomization




February 10th 2011

Introduction to Data Acquisition - W.Vandelli - ISOTDAQ2011

to here →

← from here



Friday, 5 February 2010

TDAQ Scaling - Sergio Ballestrero


Outline

- Step 1: Increasing the rate
- Step 2: Increasing the sensors
- Step 3: Multiple Front-Ends
- Step 4: Multi-level Trigger
- Step 5: Data-Flow control
- Trends etc

Step One: increasing the rate


Processing:


- Wait for ADC (poll/irq)
- Read it
- Clear it
- Re-format data
- write to disk



Derandomisation


- Processing here is an
 Buffering decouples evident bottleneck
 - the problem






Is it over? no.

 Even in a simple DAQ there are many other possible limits



Is it over? no: the sensor

- Sensors are limited by physical processes
 - drift times in gases
 - charge collection
- choose fast processes
- also the (hidden) analog
 F.E. imposes limits
- split the sensors, each gets less rate: "increase granularity"



Is it over? no: the ADC


Analog/Digital F.E. is also limited

 Faster ADCs pay the price in precision and power consumption

Alternatives:


analog buffers

 see Detector Readout lecture




Is it over? no: the Trigger

- A simple trigger is fast (so I lied, not an issue?)
- a complex trigger logic may not be so fast even when all in hardware
- to get a single answer all information must be collected in a single point
 - in one step: too many cables
 - in many steps: delays




Is it over? no: the dataflow


- Data Processing is quite easy and scalable
- Data Transport may not be easy
- Final storage is expensive (and at some point not easy either)



A little example

- HPGe + Nal Scintillator
 High res spectroscopy and beta+
 decay identification
- minimal trigger with busy logic
- Peak ADC with buffering, zero suppression
- VME SBC with local storage
- Rate limit ~14kHz
 - HPGe signal shaping for charge collection
 - PADC conversion time
- 3x12 bits data size (coincidence in an ADC channel) +32bit ms timestamp
- Root for monitor & storage







CAEN

Step two: increasing the sensors

- Multiple channels (usually with FIFOs)
- Single, all-HW trigger
- single processing unit
- single I/O




multi-channels, single FE PU



- common architecture in test beams and small experiments
- Usually the rates limited by (interesting) physics itself, not TDAQ system
- or by the sensors

Bottlenecks: PU and Storage




- A single Processing Unit can be a limit
 - collate / reformat / compress data can be heavy for an F.E. CPU
 - simultaneously writing storage
- Final storage too:
 - VME up to 50MB/s

 > 1TB in 5h
 too many disks in a week!


Laptop SATA disk: 54MB/s; USB2: ~30MB/s
TDAQ Scaling - Sergio Ballestrero

Solution: Decouple FE from Storage



- A dedicated "Data Collection" unit to format / compress and store
- Free FE for smarter processing or decreased dead time on non-buffered ADCs

Bottlenecks: Trigger?



- To reduce data rates (to avoid storage issues) a nontrivial trigger is needed.
- With the number of channels that a VME can support we may already hit manageability limits for discrete logic
- Integrated, programmable logic came to rescue


A real example: NA43/63

- Radiation emission effects: Coherent emission in crystals and structured targest, LPM suppression...
- 80~120GeV e- from CERN SPS slow extraction
- 2s spill every 13.5s

ISOT]


- Needs very high angular resolution
- Long baseline + high-res, low material detectors
 - → Drift Chambers
- 10 kHz limit on beam for radiation damage
- results in typical 2~3 kHz physics trigger

17




A real example: NA43/63

- 30~40 TDC, 6~16 QDC, 0~2 PADC (depends on measurement)
- CAMAC bus 1MB/s, no buffers, no Z.S.
- single PC readout
- NIM logic trigger (FPGA in 2009)
 - pileup rejection
 - fixed deadtime




Step Three: Multiple FEs

- LEP experiments were typical examples
- complex detectors, not very high rate physics, nor background
- little pileup, limited channel occupancy
- simpler, slow gasbased main trackers



Event Building?

- Event "fragments"
 - in detector/sectorspecific pipeline
- keep track of which event they belong to
 - timestamp or
 - L1 trigger #
- gather every fragment to single location



A minimal example



MineralPET TechDemo:


- 16 position-sensitive scintillators
- 2 * 32-Ch PeakADC
- . 1 * 64-Ch TDC
- 8 kHz readout, ~256bytes events
 - single trigger, not interested in absolute rates, so it can run near saturation

- Today's VME modules do buffering, zero suppression etc.
- best throughput achieved by block transfers of full buffers
- as soon as you use more than one module :
 - unpack blocks into events
 - merge data from same event across all sources
- "Network" design collapsed in a single system


A small size example: NA59

- 80~120GeV e- from CERN SPS slow extraction
- 2s spill every 13.5s


Radiation polarization conversion in crystals



- Drift Chambers and Delay Wire chambers
- ~10µm resolution
- ~10µrad resolution




An small size example: NA59



- Main VME+CAMAC FE
- Silicon Tracker FE
- Decoupled "Block Building" and Storage
- SPS: 2s spill in 13.5s take advantage of idle duty cycle for processing & storage
- Physics and detectors limit the rate to ~4kHz
- Event size ~280bytes
 → 840kB/s
 not far from LEP data rates!

S.Ballestrero: NA59 T&DAQ @ISOTDAQ 2010


Bottlenecks?



- Trigger complexity vs storage
- Single HW trigger is not sufficient to reduce rate
- Introduce L2 Trigger
- Introduce HLT

Step four: Multi-level trigger

Typical Trigger / DAQ structure at LEP




- More complex filters
- but slower
- applied later in the chain

see Trigger lectures

LEP

- 10⁵ channels
- 22µs crossing rate
 - . no event overlap
- single interaction
- L1 ~10³ Hz
- . L2 ~10² Hz
- L3 ~10¹ Hz
- 100 kB/ev → 1MB/s

ATLAS: oh my!




ATLAS T&DAQ Why & How, L. Mapelli @ISOTDAQ 2010


Actually, it's "just"

- Still 3-level trigger
- buffers everywhere
- L2 on CPU, not HW, but limited to ROIs
- L3 using offline algorithms
- "economical" design: the least CPU and network for the job

see "TDAQ for LHC" lecture



CMS: oh my!




CMS TDAQ Design - S. Cittolin @ISOTDAQ 2010


Actually it's "just"

- Only two trigger levels
- Intermediate event building step (RB)
- larger network switching

see "TDAQ for LHC" lecture




Step Five: Data Flow control



- Buffers are not the final solution: they can overflow
 - bursts
 - unusual event sizes
- Discard
 - local, or
 - "backpressure", tells lower levels to discard
 - up the chain to a single point, else efficiency becomes unknown


A counter-example: Kloe

- DAФNE e+e- collider in Frascati
- CP violation parameters in the Kaon system
- "factory": rare events in a high rate beam



- 10⁵ channels
- 2.7ns crossing rate
 - large event overlap
- single interaction
 - "double hit" rejection
- L1 ~10⁴ Hz
 2µs fixed dead time
- L2 ~10⁴ Hz
 ~COTS, background rejection only
- $5kB/ev \rightarrow 50MB/s$

A counter-example: Kloe



- High rate of small events
- Fixed L1 dead time: 2µs
- synchronous
- not so much need for buffering at FE
- push architecture
 vs pull used in ATLAS
 see Software lecture
- no backpressure

Trends

- Integrate synchronous, low latency in the front end
 - the limitations discussed do not disappear, but become "local"
 - all-HW implementation
 - isolated in a replaceable component
- Use networks as soon as possible

- Deal with dataflow instead of latency
- Use COTS network and processing
- Use "network" design already at small scale
 - easily get high performance with commercial components
- (6) It is easier to move a problem around (for example, by moving the problem to a different part of the overall [network] architecture) than it is to solve it. (6a) (corollary). It is always possible to add another level of indirection.

RFC 1925 The Twelve [Networking] Truths

Back to basics?

• (12) In [protocol] design, perfection has been reached not when there is nothing left to add, but when there is nothing left to take away.

RFC 1925 The Twelve [Networking] Truths


- After adding all these levels of buffering, indirection, preselection, pre-preselection..
- What if we threw it all away?

 And we looked instead (e.g. for next generation Linear Colliders) towards "triggerless" systems, where all data flows to Event Building, and selection is done fully in software?

See e.g. Patrick Le Dû @SNOWMASS 2001

SPARE SLIDES


NA59 Trigger - physical view



- Different types of events get different prescaling before readout
 - Give more chances to interesting (Rad, Pair) events, reduce storage
- Add calibration events in the mix
- Reject event if another particle arrives within drift time of DCs
 - Would not be distinguishable so no central drift chambers at LHC exp.
- Fully implemented in HW discrete NIM modules, about 2 crates

NA59: Validate Trigger & DAQ

- Instrument your DAQ for performance
 - But careful because gettimeofday yields!
- Check dead time via Δt_{event}
 - Most Probable 205µs, avg 275µs
 - minimum 170µs
 - VME readout time 160µs (bus analyzer)
 - 60µs CAMAC ADC (Lecroy 2249A)
- Compare with real rates
 - Scalers with no busy veto



NA59 Validate Trigger & DAQ

- Instrument your DAQ for performance
 - But careful because gettimeofday yields!
- Check dead time via Δt_{event}
 - Most Probable 205µs, avg 275µs
 - minimum 170µs
 - VME readout time 160µs (bus analyzer)
 - 60µs CAMAC ADC (Lecroy 2249A)
- Compare with real rates
 - Scalers with no busy veto
- Compare for different trigger types (dem)
- Analyse minimum-bias (NORM) events to check that the HW trigger cuts actually behave as expected

