



The HERD Space Mission



Timing resolution checks at GSSI


Contents

Goal: to assess the intrinsic timing properties of bar+SiPM only Waveform Analysis


Timing Tests at GSSI:

- Two bars (the 10&13 assembled in XY in the prototype tested at CERN, two SiPMs per bar, readout in OR) tested in January;
- Two bars (different in size and material, superimposed, one SiPM per bar), tested in December 2021 (reported already at the PSD meeting);
- •Two bars (same size and material, superimposed, two SiPMs per bar, readout in OR), tested this week.


Waveform analysis



The analysis is performed at the waveform level by measuring relevant parameters (Rise Time (i.e. 20%–80%), Max Amplitude, Baseline)



Timing properties of the system composed of two orthogonal scintillating bars 10 & 13 embedded in the prototype tested at CERN




Components

- SiPM1 and SiPM2 are readout in OR, same for SiPM3 and SiPM4 (Vbias~ 45 V)
- Linear LV Power Supply to operate the SiPMs
- Both SiPMs are readout by means of a Lecroy HD06104 oscilloscope (1 GHz bandwidth, 2.5 GS/s)


NB:


- The OR mode brings in the effect of gain non uniformity and the intrinsic jitters of the two SiPMs in each bar.
- High intensity scintillation light regime (assuming an average gain of $5x10^5$ (TBC))



Time delay Δt between SiPM1-SiPM2 (using the position of the 40% of max amplitude)

 $\Delta t = t_{SiPM1} - t_{SiPM2}$






Possible improvements:

- Use one SiPM only per each bar;
- Noise Hunting (challenging);
- Faster electronics (or HDO with higher performance,
 i.e. higher sampling rate);
- Cleaner setup (always possible).

Timing properties of the system composed of two superimposed scintillating bars different in dimensions and material



Components

SiPM 1, SiPM 2: Hamamatsu S13360 — 3025CS

Scintillator coupled to SiPM1: Eljen (EJ 200)


Scintillator coupled to SiPM2: Saint-Gobain (BC-404)

Linear LV Power Supply to operate the SiPMs

Both SiPMs are readout by means of a Lecroy HD06104 oscilloscope (1 GHz bandwidth, 2.5 GS/s)

NB:


- SiPM 1 and SiPM 2 are operated at same gain (from previous measurements, 5x10⁵ @ 56V, ~room T)
- The trigger is active when both SiPM 1 and SiPM2 produce a signal ($V_{thr} > 5 \text{ mV}$) in a time window of 200 ns




Time delay: a good estimator for the time resolution

Time delay Δt between SiPM1-SiPM2 (using the position of the 20% of max amplitude)

 $\Delta t = t_{SiPM1} - t_{SiPM2}$






Possible improvements:

- Use identical scintillating bars, same coupling, equalisation of SiPM gains;
- Hardware implementation of a Constant Fraction
 Discriminator;
- Faster electronics (or HDO with higher performance,
 i.e. higher sampling rate);
- Cleaner setup (always possible)

Timing properties of the system composed of two superimposed identical scintillating bars




Components

- SiPM1 and SiPM2 are readout in OR, same for SiPM3 and SiPM4 (Vbias~ 45 V)
- **Linear LV Power Supply to operate the SiPMs**
- Both SiPMs are readout by means of a Lecroy HD06104 oscilloscope (1 GHz bandwidth, 2.5 GS/s)

NB:

- The OR mode brings in the effect of gain non uniformity and the intrinsic jitters of the two SiPMs in each bar.
- High intensity scintillation light regime (assuming an average gain of 5x10⁵ (TBC))





Time delay: a good estimator for the time resolution

Time delay Δt between SiPM1-SiPM2 (using the position of the 30% of max amplitude)

 $\Delta t = t_{SiPM1} - t_{SiPM2}$

Selected Sample: <TimeDelay>±2.65 STD





Possible improvements:

- Use one SiPM only per each bar;
- Noise Hunting (challenging);
- Faster electronics (or HDO with higher performance,
 i.e. higher sampling rate);
- Cleaner setup (always possible).

Conclusions

We have tested the time features of three different systems:

- 1.Two bars (the 10&13 assembled in XY in the prototype tested at CERN, two SiPMs per bar, readout in OR);
- 2. Two bars (different in size and material, superimposed, one SiPM per bar);
- 3. Two bars (identical, superimposed, two SiPMs per bar, readout in OR).

The best timing response has been obtained for option 3 (t_{res} <300 ps)

Currently, the t_{res} measurement (option 3) seems to be dominated by:

- 1. the readout electronics being used (HD06104 Lecroy oscilloscope, 1 GHz BDW, 2.5 GS/s);
- 2. the two SiPM readout in OR (intrinsic jitter, gain difference, larger capacitance);
- 3. operations at high intensity light regime (no pre-amp stage in use).

Room for improvements:

- 1. Faster readout:
- 2. External Trigger;
- 3. SiPM individually operated and read out;
- 4. Cleaner setup and noise hunting.