

► HIGH POWER LASERS FOR 3RD GENERATION GRAVITATIONAL WAVE DETECTORS

P. Weißels
for the LZH high power laser
development team

Laser Zentrum Hannover, Germany
23.05.2011

OUTLINE

Requirements on lasers for 3rd generation gravitational wave detectors

Experimental results:

- ▶ Fiber amplifier results: 1064 nm
- ▶ Fiber amplifier results: 1.5 μm
- ▶ Coherent beam combining

Summary

LASERS FOR 3RD GENERATION GWD

There is no final design for a 3rd generation gravitational wave detector.

There are no final laser specifications.

Development targets?


- ▶ Wavelength?
- ▶ Output power?
- ▶ Beam shape?

TWO LASERS!

Look in Einstein Telescope (ET) Design Study Document:


Laser 1:

- ▶ Wavelength: 1064 nm
- ▶ Output power: 500 W
- ▶ Beam shape: LG_{33}



Laser 2:

- ▶ Wavelength: 1.5 μm
- ▶ Output power: 3 W
- ▶ Beam shape: TEM_{00}



All power values after IMC!

But: Requirements might change with interferometer design:

- ▶ Potential problems with LG_{33} in high finesse interferometer
- ▶ High power @ 1.5 μm might still be needed

Lasers @ 1064 nm

PART 1: LASERS @ 1064 nm

Long term design goal: 1 kW @ 1064 nm

At this stage: Mode shape TEM₀₀

**Mode conversion from TEM₀₀ to LG₃₃ is treated as independent problem
(→ will not be covered in this presentation)**

Approach:

- ▶ Single-frequency Master Oscillator Fiber Amplifier (MOFA) concept
→ NPRO + Ytterbium-doped fiber amplifier(s)
- ▶ All polarization maintaining (PM) fibers

- ▶ Also working on high power solid state amplifier systems
(→ will not be covered in this presentation)

STATE OF THE ART OF PM-MOFAS @ 1064 nm

Power scaling of PM single-frequency MOFAs up to 500 W*

- ▶ Customized fiber designs: fiber designs tested for power scaling (SBS threshold), not yet commercially available
- ▶ Only M^2 measurements for beam quality characterization


TEM₀₀-mode content measurements only for system delivering up to 148 W of output power**

- ▶ Amplifier fiber: photonic crystal fiber with a MFD of 22 μm
- ▶ Pump- and seed-power limited (single-stage setup)
- ▶ Non-PM, though good PER
- ▶ TEM₀₀-mode content: 92.6 %

* Gray et al. (2007), Robin et al. (2011), Zhu et al. (2011)

** Hildebrandt et al. (2006)

SETUP OF TWO-STAGE Yb-DOPED FIBER MOPA



Seed

500 mW NPRO

With ~1 kHz linewidth

Pre-Amplifier

Nufern PM-YDF-10/125

$P = 10 \text{ W}$


(seed for main amp)

Pump modules

Fiber coupled,

Emitting at 976 nm

NKT PHOTONICS DC-400-40-PZ-YB





Outer cladding diameter: 700 μm

Pump cladding diameter: 400 μm

Pump cladding NA: 0.6

Nominal absorption at 976 nm: 2.4 dB/m



Core diameter: 40 μm

Core NA: 0.03


MFD: 29 μm

Pitch: 9.97 μm

d/pitch: 0.14


MAIN AMPLIFIER WITH 6.8 m PCF

Output power



- ▶ Maximum absorbed pump power: 363 W
- ▶ Maximum signal output power: 294 W
- ▶ Slope efficiency: 80 %
- ▶ PER: ~ 27 dB
- ▶ No evidence of SBS

Higher order mode content



- ▶ Higher order mode content increases slightly with increasing amplifier output power

Lasers @ 1.5 μm

PART 2: LASERS @ 1.5 μm

Long term design goal: $\gg 100\text{ W}$ @ 1.5 μm

Design approach: Single-frequency master laser + fiber amplifier

Active dopants: Erbium *or* Erbium/Ytterbium

BASIC COMPARISON OF 1.0 μm AND 1.5 μm

Wavelength	1.0 μm	1.5 μm
Dopant	Yb	Er/Yb, Er
typ. Efficiency	up to 85%	up to 30%
Quantum defect	$\sim 10\%$	30-70%
rel. absorption cross section	~ 10	1
rel. dopant concentration	~ 10	1
Highest Output Power	~ 500 W (SBS limited)*	~ 150 W (high NA fiber, Yb-ASE limited)**



* Jeong et al. , IEEE JSTQE 13, 546 (2007)

** Jeong et al., OL 30, 2997(2005)

At 1.5 μm :

- ▶ More pump light is needed for same output power
- ▶ Far more heat is generated

CHALLENGES TO POWER SCALING / Er-DOPING



- ▶ Absorption cross sections and possible doping concentrations lead to about two magnitudes lower absorption compared with Yb-doping
- ▶ Er fibers need higher pump brightness due to smaller pump claddings
- ▶ Upconversion and ESA processes can increase the quantum defect to about 70 %

* Laroche et al., JOSA B 23, 195-202 (2006)


ALTERNATIVE: Er/Yb CO-DOPING

Concept & Advantages:

- ▶ Pump light absorption mainly by Yb
- ▶ Transfer from $F_{5/2}$ to quasi-resonant $Er-I_{11/2}$ level
- ▶ Significantly higher absorption cross sections
- ▶ “Classic” double-clad high power approach possible
- ▶ Far less pump brightness required due to smaller required core-to-cladding-ratio

Drawbacks:

- ▶ Heavy phosphorous codoping needed for depletion of backtransfer
→ typically high core NA (~ 0.2)
- ▶ Yb pump rate increase beyond Er-Yb-transfer rate causes large gain values at $1.0\ \mu\text{m}$




Er/Yb – FIBER DESIGN ISSUES

High core NA due to phosphorous-codoping

- ▶ Can be reduced by making a Ge-pedestal
- ▶ Use of fiber tapers and targeted single-mode excitation*
 - To be tested for large-core fibers

Low core-to-cladding ratio might lead to preferential operation at 1535 nm (Er emission maximum)

Fiber drawing and processing is especially difficult



* Morasse et al., Photonics West 2009

** Nufern, Photonics West 2009

TESTED CONFIGURATIONS

Both Er as well as Er/Yb codoped fibers are being examined

Er/Yb codoping:

- ▶ How to handle parasitic gain and emission at 1 μm ?

Tested fiber designs:

- ▶ “Standard” step-index LMA fibers
- ▶ Novel multifilament-core (MFC) fibers
- ▶ Specially designed photonic crystal fibers (PCF)

TESTED CONFIGURATIONS

Both Er as well as Er/Yb codoped fibers are being examined

Er/Yb codoping:


- ▶ **How to handle parasitic gain and emission at 1 μm ?**

Tested fiber designs:

- ▶ “Standard” step-index LMA fibers
- ▶ Novel multifilament-core (MFC) fibers
- ▶ **Specially designed photonic crystal fibers (PCF)**


How to handle parasitic gain and emission at 1 μm ?

Er/Yb – MANAGE 1 μ m EMISSION – SETUP (1)




- ▶ 80 mW seed power at 1556 nm, linewidth < 10 MHz
- ▶ Co-propagating pumping configuration with 6+1 x 1 TFB-coupler
- ▶ 6x6 W of pump power at 976 nm
- ▶ Active fiber: 9.5 m of double-clad 7/130 μ m Er:Yb-codoped fiber (Nufern)
- ▶ 1060/1550 WDM coupler to protect seed from Yb-ASE

Er/Yb – MANAGE 1 μ m EMISSION – RESULTS (1)



- ▶ Slope Efficiency: 25 %
- ▶ Yb-ASE rises strongly for pump power > 6 W
- ▶ Limitation set by necessity to avoid parasitic lasing at 1.0 μ m

Er/Yb – MANAGE 1 μ m EMISSION – SETUP (2)





Inject 2nd seed signal at 1064 nm simultaneously

Auxiliary seed signal extracts excess energy from the Yb-ions

- ▶ Gain at 1.0 μ m is clamped to large signal value
- ▶ Reliable suppression of parasitic lasing and/or giant pulse formation
- ▶ Potential efficiency depletion at 1.5 μ m by competing signal?


Er/Yb – MANAGE 1 μm EMISSION – RESULTS (2)



- ▶ Er slope efficiency not degraded by co-seeding
- ▶ Slight rollover at > 6 W power at 1556 nm
- ▶ 3 W of Yb output
 - Increased efficiency by fiber length optimization seems feasible (reabsorption of 1 μm signal \rightarrow pump source for 1.5 μm signal)


Power scaling with specially designed photonic crystal fiber (PCF)

AMPLIFIER SETUP



- ▶ Seed: 2 W single-frequency DFB fiber laser @ 1556 nm
- ▶ Counter-propagating pump
- ▶ Free space coupling for pump and seed light
- ▶ Active fiber: Custom made Er-doped PCF
 - ▶ Core size: 40 μm , NA: < 0.04
 - ▶ Mode field diameter: 31 μm
 - ▶ Pump cladding: 170 μm , NA: > 0.55
 - ▶ Absorption @ 976 nm: 0.6 dB/m
 - ▶ Fiber length: 19 m

AMPLIFIER RESULTS




- ▶ Maximum output power: 70.8 W
- ▶ Slope efficiency: 18.5 %
- ▶ Limited by available pump power / amplifier efficiency
- ▶ ASE suppression: 44 dB

Coherent Beam Combining (CBC)

PART 3: COHERENT BEAM COMBINING

Coherent Beam Combining (CBC) architectures:



- ▶ Split seed into N channels
- ▶ Amplify each channel separately
- ▶ Use phase actuator to stabilize relative phase in each path
- ▶ Coherently combine in the end
 - ▶ Tiled aperture (beam quality is limited)
 - ▶ **Collinear combining (best possible beam quality)**

WHY COHERENT BEAM COMBINING?

Single frequency fiber amplifier power scaling limited by


- ▶ Stimulated Brillouin Scattering
- ▶ Thermal effects

Coherent Beam Combining allows to overcome these limits

- ▶ Add coherently multiple (power limited) beams
- ▶ Scalable by increasing number of channels

But: Beam quality and noise properties of combined beam?

CBC SETUP




- ▶ 2x 10 W single-mode Yb-doped PM amplifier @ 1064 nm
- ▶ Free space combining to avoid fiber coupler limitations
- ▶ Use proven actuators
 - ▶ EOM
 - ▶ Piezo mounted mirror




CBC RESULTS – POWER AND BEAM QUALITY

- ▶ Single amplifier output: 11.4 W
- ▶ Max CBC output: 21.8 W
- ▶ CBC efficiency: 95-97 %
 - ▶ Over the whole slope
 - ▶ Pump power was fine-tuned to maximize combining efficiency
- ▶ Stable under laboratory conditions
- ▶ TEM₀₀ content: 97%
 - ▶ Both for single amplifier and combined signal
- ▶ Transmission through locked cavity: 21.3 W




POWER AND FREQUENCY NOISE

Power noise



Frequency noise



**Combined power and frequency noise dominated by single-amplifier
→ Promising approach for further power scaling**



SUMMARY

Fiber amplifier system @ 1064 nm

- ▶ Maximum output power: 294 W
- ▶ TEM₀₀ content > 90%

Fiber amplifier system @ 1.5 μm

- ▶ Suppression/stabilization scheme for 1 μm parasitic emission demonstrated
- ▶ Maximum output power of PCF amplifier system: > 70 W
- ▶ TEM₀₀ content ~ 80%

Coherent beam combining testbed

- ▶ Combining efficiency of 2x 10 W amplifier ~ 97 %
- ▶ TEM₀₀ content ~ 97%
- ▶ No degradation of power and frequency noise compared to single amplifier

ACKNOWLEDGEMENTS


3rd generation laser development team:

Henrik Tünnermann


Chandrajit Basu

Malte Karow

Vincent Kuhn



DFG Deutsche
Forschungsgemeinschaft

 **Centre for Quantum Engineering
and Space-Time Research**
quest

 **HALOSTAR**
Hannover School for Laser, Optics and Space-Time Research

► **THANK YOU FOR YOUR ATTENTION**

Laser Zentrum Hannover, Germany
23.05.2011