

Recent results and perspectives of the Monopix Depleted Monolithic Active Pixel Sensors (DMAPS)


M. Barbero⁴, P. Barrillon⁴, C. Bepin¹, P. Breugnon⁴, I. Caicedo¹, Y. Degerli³, J. Dingfelder¹, T. Hemperek¹, T. Hirono¹, F. Hügging¹, H. Krüger¹, K. Moustakas¹, P. Pangaud⁴, H. Pernegger², P. Riedler², P. Rymaszcwski¹, L. Schall¹, P. Schwemling³, W. Snoeys², T. Wang¹, N. Wermes¹ and S. Zhang¹

¹Universität Bonn, ²CERN, ³IRFU CEA-Saclay, ⁴CNRS/IN2P3 CPPM Marseille

The Monopix design

The Monopix design implements monolithic active pixel detectors in commercial CMOS imaging technologies. High-resistivity substrates with high-voltage capabilities facilitate depletion of the charge-sensitive volume, maximizing the charge collection potential and enabling fast signal generation by drift.

The presented prototypes, TJ-Monopix2 and LF-Monopix2, differ in the size of the readout electrode relative the pixel area. The small collection electrode approach (TJ-Monopix2) offers low analog power consumption and minimal noise operation due its low detector capacitance. Its sensor geometry has to be tuned carefully to achieve a significant radiation tolerance ($> 10^{14}$ 1 MeV neq cm⁻²). A design with large collection electrode (LF-Monopix2) that houses all in-pixel readout electronics exhibits a larger radiation tolerance by default at the cost of a higher detector capacitance.




TJ-Monopix2:

- 180 nm TowerSemi technology
- 512 x 512 pixels of 33 x 33 μm^2 each
- 7-bit ToT energy measurement @ 40 MHz
- 3-bit in-pixel tuning DAC
- O(2 fF) detector capacitance
- 1 μW per pixel analog power

LF-Monopix2:


- 150 nm LFoundry technology
- 56 x 340 pixels of 150 x 50 μm^2 each
- 6-bit ToT energy measurement @ 40 MHz
- 4-bit in-pixel tuning DAC
- O(250 fF) detector capacitance
- 28 μW per pixel analog power



Front-end working principle


According to $V = Q / C$, the front-end input signal in TJ-Monopix2 is considerably larger than in LF-Monopix2 and can be amplified with a single-stage voltage amplifier while LF-Monopix2 makes use of a conventional charge-sensitive amplifier.

The matrix of both prototypes is read out using an established column-drain architecture derived from the FE-I3 readout chip.



Threshold response

Under typical operating conditions, the prototypes achieve a threshold response of 200 e⁻ and 2000 e⁻ for TJ-Monopix2 and LF-Monopix2, respectively, with most probable charge values of 2500 e⁻ and 6000 e⁻ for minimally ionizing particles.






LF-Monopix2 exhibits an equivalent noise charge (ENC) of approx. 100 e⁻, while the small detector capacitance in TJ-Monopix2 is beneficial for noise levels as low as 5 e⁻.

Radiation hardness

With dedicated design efforts, the breakdown voltage of LF-Monopix2 is increased to larger than 450 V before irradiation. The ENC increases from 90 e⁻ to 180 e⁻ after a NIEL fluence of 2 x 10¹⁵ neq cm⁻². Its large bias voltage capabilities allow for hit detection efficiencies above 99 % at these NIEL fluence levels.


NIEL fluence [neq]	0	1 x 10 ¹⁵	2 x 10 ¹⁵
Threshold [e ⁻]	2040	2090	2070
ENC [e ⁻]	87	120	178



In the TJ-Monopix design series, a modification has been developed together with the foundry to increase the radiation hardness of the small collection electrode design. In this geometry, hit detection efficiencies above 98 % could be achieved at a NIEL fluence of 1 x 10¹⁵ neq cm⁻². A lower detection threshold in TJ-Monopix2 is expected to reduce the losses in the pixel corners for a more homogeneous detection efficiency above 99 %.

Timing performance


The amplifier implemented in TJ-Monopix2 facilitates fast detection of the deposited charge with a time resolution of less than 100 ps for charge values in the order of the most probable charge of minimally ionizing particles. Measurements in particle beams demonstrate a total time resolution of the pixel of about 1.3 ns (time walk corrected) which is dominated by physics processes and propagation delays within the pixel (up to 3 ns without time walk correction).



Conclusion & Outlook

Both presented depleted monolithic active pixel sensors demonstrate a good performance for high-radiation and high-rate environments in particle physics experiments. LF-Monopix2 exceeds its target radiation tolerance (1 x 10¹⁵ neq cm⁻²) with no significant degradation at the available NIEL fluences.

TJ-Monopix2 offers a high granularity and fast readout combined with a low power consumption. First results hint to an improved radiation tolerance compared to its predecessor. With its performance, it serves as a baseline for a future Belle II vertex detector in the same CMOS technology.



F. Forti Snowmass Whitepaper: The Belle II Detector Upgrade Program arXiv:2203.11349

This project has received funding from the Deutsche Forschungsgemeinschaft DFG (grant WE 976/4-1), the German Federal Ministry of Education and Research BMBF (grant 05H15PDCA9), and the European Union's Horizon 2020 research and innovation program under grant agreements no. 675587 (Maria Skłodowska-Curie ITN STREAM), 654168 (AIDA-2020), and 101004761 (AIDAInnova) and the European Union's Horizon Europe Research and Innovation programme under grant agreement no. 101057511. The measurements leading to these results have been performed at the Test Beam Facility at DESY Hamburg (Germany), a member of the Helmholtz Association (HGF).

