

# **GEANT4** materials & geometry

---

A lot of material by J. Pipek      Pablo Cirrone

**INFN – Laboratori Nazionali del Sud**

`Pablo.cirrone@lns.infn.it`

**Geant4 Course**

at the XXI Seminar on software for nuclear, subnuclear and  
applied physics

Alghero, June 9<sup>th</sup>- 14<sup>th</sup>, 2024

# Mandatory (and optional) user classes

**At initialization**

**At execution**

G4VUserDetectorConstruction

G4VUserPhysicsList

G4VUserActionInitialization

main()  
function

G4VUserPrimaryGeneratorAction


G4UserRunAction

G4UserEventAction

G4UserStackingAction

G4UserTrackingAction

G4UserSteppingAction



# Mandatory (and optional) user classes

**At initialization**

**At execution**

G4VUserDetectorConstruction

G4VUserPhysicsList

G4VUserActionInitialization

main()  
function

G4VUserPrimaryGeneratorAction


G4UserRunAction

G4UserEventAction

G4UserStackingAction

G4UserTrackingAction

G4UserSteppingAction



# The Detector Construction

- User class which describes the geometry must inherit from **G4VUserDetectorConstruction** and registered in the Run Manager
- Define the geometry of your model
  - All materials
  - All volumes & placements
- (Optionally) add fields
- (Optionally) define volumes for read-out (sensitive detectors)

```
// ...
class G4VUserDetectorConstruction
{
public:
    G4VUserDetectorConstruction();
    virtual ~G4VUserDetectorConstruction();

public:
    virtual G4VPhysicalVolume* Construct() = 0;
    virtual void ConstructSDandField();
    // ...
}
```



Remember!





# Part I: Units

---



# Note: Geant4 basic types

---

- Aliases for the **primitive data types** to provide cross-platform compatibility:
  - `G4double`, `G4float`, `G4int`, `G4bool`, `G4long`
- Enhanced version of string called **G4String**
  - inherits from `std::string` ⇒ all methods and operators
  - several additional methods
- **G4ThreeVector** is a three-component class corresponding to a real physics vector (examples later)

```
G4ThreeVector dimensions {1.0, 2.0, 3.0 };
```

Please, use these types for best compatibility (e.g. `G4int` instead of `int`, etc., `G4ThreeVector` when it makes sense etc.)



# Units in Geant4

- **Don't use default units!**

- When specifying dimensions, always **multiply** by an appropriate unit:

```
G4double width = 12.5 * m;  
G4double density = 2.7 * g/cm3;
```

- Most common units are defined in **CLHEP** library (included in Geant4):

```
▶ G4SystemOfUnits.hh
```

```
▶ CLHEP/SystemOfUnits.hh
```

- You can define **new units**

- **Output data** in terms of a specific unit:

- **divide** a value by the unit:

```
G4cout << dE / MeV << " (MeV)" << G4endl;
```



# System of units in Geant4

nanosecond (ns)

unit charge (eplus)

megaelectronvolt (MeV)

radian

kelvin

millimeter (mm)

candela

steradian

- All other units derived from the basic ones.
- **Useful feature:** Geant4 can select the most appropriate unit to use
  - specify the **category** for the data (**Length, Time, Energy**, etc...):

```
G4cout << G4BestUnit(StepSize, "Length");
```

**StepSize** will be printed in **km, m, mm** or ... **fermi**, depending on its actual value



# Defining new units

---

- **New units** can be defined directly as constants, or (suggested way) via **G4UnitDefinition**
  - `G4UnitDefinition ( "name", "symbol", "category", value )`
- Example (mass thickness):
  - `G4UnitDefinition ("grampercm2", "g/cm2", "MassThickness", g/cm2);`
  - The **new category** "MassThickness" will be registered in the kernel in G4UnitsTable
- To **print the list of units**:
  - From the code  
`G4UnitDefinition::PrintUnitsTable();`
  - At run-time, as UI command:  
`Idle> /units/list`



# Part II: Materials

---



# Materials

---

- Different levels of material description:
  - isotopes → **G4Isotope**
  - elements → **G4Element**
  - molecules → **G4Material**
  - compounds and mixtures → **G4Material**
- Attributes associated:
  - **Density** (mandatory)
  - Temperature, Pressure, State (gas, liquid, ...)



# Materials

---

- **G4Isotope** and **G4Element** describe properties of the **atoms**:
  - **Atomic number**, number of nucleons, mass of a mole, **shell energies**, **cross-sections** per atoms, etc...
- **G4Material** describes the **macroscopic properties** of the matter:
  - temperature, pressure, state, **density**
  - **Radiation length**, absorption length, etc...
- **G4Material** is used by **tracking**, **geometry** and **physics** in Geant4
  - Material properties computed from elemental properties → assumption of **linear combination**





# Elements and isotopes

- If you need an element made by a non-natural isotopic composition (e.g.  $^{\text{enr}}\text{Ge}$ )
- Build **isotopes**

```
G4Isotope(const G4String& name,  
          G4int      z,      // atomic number  
          G4int      n,      // number of nucleons  
          G4double   a );   // mass of mole
```

- ... and **assemble** into elements

```
G4Element (const G4String& name,  
           const G4String& symbol, // element symbol  
           G4int      nIso );     // n. of isotopes
```

```
G4Element::AddIsotope(G4Isotope* iso, // isotope  
                      G4double relAbund); // fraction of nuclei
```



## ... for instance

- Build <sup>enr</sup>U

Do not forget unit (g/mole)

```
G4Isotope* U5 = new G4Isotope(name="U235", iz=92, n=235,  
    a=235.01*g/mole);  
G4Isotope* U8 = new G4Isotope(name="U238", iz=92, n=238,  
    a=238.03*g/mole);  
G4Element* e1U = new G4Element(name="enriched Uranium", symbol="U",  
    ncomponents=2);  
e1U->AddIsotope(U5, abundance= 90.*perCent);  
e1U->AddIsotope(U8, abundance= 10.*perCent);
```

- For element with *natural isotopic composition*,  
definition is easier

Do not forget unit (g/mole)

```
a = 16.00*g/mole;  
G4Element* e10 = new G4Element("Oxygen", symbol="O", z=8., a);  
G4cout << e10 << G4endl; //printout of element info
```



# Elements and molecules

- Single-element materials

```
G4double z, a, density;  
density = 1.390*g/cm3;  
a = 39.95*g/mole;  
G4Material* lAr = new G4Material("liquidAr", z=18, a, density);
```

- Molecule (composition by *number of atoms*)

```
a = 1.01*g/mole;  
G4Element* e1H = new G4Element("Hydrogen", symbol="H", z=1., a);  
  
a = 16.00*g/mole;  
G4Element* e1O = new G4Element("Oxygen", symbol="O", z=8., a);  
  
density = 1.000*g/cm3;  
G4Material* H2O = new G4Material("Water", density, ncomponents=2);  
H2O->AddElement(e1H, natoms=2);  
H2O->AddElement(e1O, natoms=1);
```



# Materials: compounds

---

- Composition by fraction of mass

```
a = 14.01*g/mole;  
G4Element* e1N = new G4Element(name="Nitrogen",symbol="N", z= 7., a);  
a = 16.00*g/mole;  
G4Element* e1O = new G4Element(name="Oxygen",symbol="O", z= 8., a);  
density = 1.290*mg/cm3;  
G4Material* Air = new G4Material(name="Air", density, ncomponents=2);  
Air->AddElement(e1N, 70.0*perCent);  
Air->AddElement(e1O, 30.0*perCent);
```



# Materials: mixtures

---

- Composition of mixtures

```
G4Element* e1C = ...; // define "carbon" element
G4Material* SiO2 = ...; // define "quartz" material
G4Material* H2O = ...; // define "water" material
density = 0.200*g/cm3;

G4Material* aerogel = new G4Material("Aerogel",
                                   density, ncomponents=3);
aerogel->AddMaterial(SiO2, fractionmass=62.5*perCent);
aerogel->AddMaterial(H2O, fractionmass=37.4*perCent);
aerogel->AddElement (e1C, fractionmass= 0.1*perCent);
```



# Example: a gas

---

- It may be necessary to specify temperature and pressure
  - (dE/dx computation affected)

```
G4double density = 27. * mg/cm3;  
G4double temperature = 325. * kelvin;  
G4double pressure = 50. * atmosphere;  
  
G4Material* C02 = new G4Material("C02Gas", density,  
    ncomponents=2, kStateGas, temperature, pressure);  
C02->AddElement(C, natoms = 1);  
C02->AddElement(O, natoms = 2);
```



# "Vacuum"

---

- Absolute vacuum does not exist:
  - Model it as a gas at **very low density!**
  - **Cannot define** materials composed of multiple elements through Z or A, or **with  $\rho=0$**

```
G4double atomicNumber = 1.;
G4double massOfMole = 1.008*g/mole;
G4double density = 1.e-25*g/cm3;
G4double temperature = 2.73*kelvin;
G4double pressure = 3.e-18*pascal;

G4Material* Vacuum = new G4Material("interGalactic",
    atomicNumber, massOfMole, density,
    kStateGas, temperature, pressure);
```



# The NIST database

- All elements and many commonly-used materials available in Geant4 through the NIST database
- No need to predefine elements and materials
- Retrieve materials from NIST manager:

```
G4NistManager* manager = G4NistManager::Instance();  
G4Material* H2O = manager->FindOrBuildMaterial("G4_WATER");  
G4Material* vacuum = manager->FindOrBuildMaterial("G4_Galactic");
```

- UI commands

```
/material/nist/printElement
```

← print defined elements

```
/material/nist/listMaterials
```

← print defined materials



# The NIST database: elements

- NIST database for elements and materials is imported in Geant4
  - <http://physics.nist.gov/PhysRefData>
- UI commands specific for handling materials
- The **best accuracy** for the most relevant **parameters** guaranteed:
  - Density
  - Mean excitation potential
  - Element composition
  - Isotope composition
  - Various corrections

Z	A	m	error	(%)	A <sub>eff</sub>
14	Si	22	22.03453	(22)	28.0855(3)
		23	23.02552	(21)	
		24	24.011546	(21)	
		25	25.004107	(11)	
		26	25.992330	(3)	
		27	26.98670476	(17)	
		28	27.9769265327	(20)	92.2297 (7)
		29	28.97649472	(3)	4.6832 (5)
		30	29.97377022	(5)	3.0872 (5)
		31	30.97536327	(7)	
		32	31.9741481	(23)	
		33	32.978001	(17)	
		34	33.978576	(15)	
		35	34.984580	(40)	
		36	35.98669	(11)	
		37	36.99300	(13)	
		38	37.99598	(29)	
		39	39.00230	(43)	
		40	40.00580	(54)	
		41	41.01270	(64)	
		42	42.01610	(75)	

- **Natural** isotope **compositions**
- More than 3000 isotope masses

# NIST materials

```

=====
### Elementary Materials from the NIST Data
=====
Z Name ChFormula density(g/cm^3) I(eV)
=====
1 G4_H H_2 8.3748e-05 19.2
2 G4_He 0.000166322 41.8
3 G4_Li 0.534 40
4 G4_Be 1.848 63.7
5 G4_B 2.37 76
6 G4_C 2 81
7 G4_N N_2 0.0011652 82
8 G4_O O_2 0.00133151 95
9 G4_F 0.00158029 115
10 G4_Ne 0.000838505 137
11 G4_Na 0.971 149

```

```

=====
### Compound Materials from the NIST Data Base
=====
N Name ChFormula density(g/cm^3) I(eV)
=====
13 G4_Adipose_Tissue 0.92 63.2
1 0.119477
6 0.63724
7 0.00797
8 0.232333
11 0.0005
12 2e-05
15 0.00016
16 0.00073
17 0.00119
19 0.00032
20 2e-05
26 2e-05
30 2e-05
4 G4_Air 0.00120479 85.7
6 0.000124
7 0.755268
8 0.231781
18 0.012827
2 G4_Csl 4.51 553.1
53 0.47692
55 0.52308

```

- NIST Elements:
  - H → Cf ( Z = 1 → 98 )
- NIST compounds:
  - e.g. "G4\_ADIPOSE\_TISSUE\_IRCP"
- HEP and Nuclear materials:
  - e.g. Liquid Ar, PbWO
- Possible to build **mixtures** of NIST and **user-defined** materials



# Part III: Geometry

---



# Describe your detector

---

- A detector geometry is made of a number of volumes
- The largest volume is called **World** volume
  - It **must** contain **all other volumes**
- Derive your own concrete class from `G4VUserDetectorConstruction` abstract base class
- Implementing the **virtual methods** `Construct()` (**pure virtual**) and `ConstructSDandFields()`:
  - Define **shapes/solids** required to describe the geometry
  - Construct all necessary **materials**
  - **Construct** and **place** volumes of your detector geometry
  - (Define "**sensitivity**" properties associated to volumes)
  - (Associate **magnetic field** to detector regions)
  - (Define **visualization** attributes for the detector elements)

# Geometry: implementation basics

- Implement a class inheriting from the abstract base class **G4VUserDetectorConstruction**:

```
class MyDetector : public G4VUserDetectorConstruction {
public:
    virtual G4VPhysicalVolume* Construct();        // required

    virtual void ConstructSDAndField();           // optional
    // ...
};
```

- Create an instance in the main program:


```
MyDetector* detector = new MyDetector();
runManager->SetUserInitialization(detector);
```

- Note: Split the implementation into more classes and methods! (good programming practice)
- Note2: you should not delete the **MyDetector** instance! Run manager does that automatically.




# G4VUserDetectorConstruction

---

- Method **Construct()**
  - Define materials
  - Define solids and volumes of the geometry
  - Build the tree hierarchy of volumes
  - Define visualization attributes
  - Return the **world physical volume!** 
- Method **ConstructSDAndField()** **MT**
  - Assign magnetic field to volumes / regions
  - Define sensitive detectors and assign them to volumes

# Three conceptual layers

- **G4VSolid**
  - *Shape, size*
- **G4LogicalVolume**
  - Hierarchy of volumes, *material*, sensitivity, magnetic field
- **G4VPhysicalVolume**
  - *Position, rotation. The same logical volume can be placed many times* (repeated modules)




# Define detector geometry

Solid: shape and size.

## ■ Basic strategy

```
G4VSolid* pBoxSolid =  
    new G4Box("aBoxSolid",  
             1.*m, 2.*m, 3.*m);  
G4LogicalVolume* pBoxLog =  
    new G4LogicalVolume( pBoxSolid,  
                         pBoxMaterial, "aBoxLog", 0, 0, 0);  
G4VPhysicalVolume* aBoxPhys =  
    new G4PVPlacement( pRotation,  
                      G4ThreeVector( posX, posY, posZ),  
                      pBoxLog, "aBoxPhys", pMotherLog, 0, copyNo);
```



**Step 1**  
Create the  
geom. object:  
box




# Define detector geometry

Logical volume : + material, sensitivity, etc.

## ■ Basic strategy

```
G4VSolid* pBoxSolid =  
    new G4Box("aBoxSolid",  
            1.*m, 2.*m, 3.*m);  
G4LogicalVolume* pBoxLog =  
    new G4LogicalVolume( pBoxSolid,  
    pBoxMaterial, "aBoxLog", 0, 0, 0);  
G4VPhysicalVolume* aBoxPhys =  
    new G4PVPlacement( pRotation,  
    G4ThreeVector( posX, posY, posZ),  
    pBoxLog, "aBoxPhys", pMotherLog, 0, copyNo);
```



Step 1

Create the  
geom. object:  
box



Step 2

Assign properties  
to object : material


# Define detector geometry

Physical volume : + rotation and position

## ■ Basic strategy

```
G4VSolid* pBoxSolid =  
    new G4Box("aBoxSolid",  
            1.*m, 2.*m, 3.*m),  
G4LogicalVolume* pBoxLog =  
    new G4LogicalVolume( pBoxSolid,  
    pBoxMaterial, "aBoxLog", 0, 0, 0);
```

```
G4VPhysicalVolume* aBoxPhys =  
    new G4PVPlacement( pRotation,  
    G4ThreeVector( posX, posY, posZ),  
    pBoxLog, "aBoxPhys", pMotherLog, 0, copyNo);
```







**Step 1**  
Create the  
geom. object:  
box

**Step 2**  
Assign properties  
to object : material

**Step 3**  
Place it in the coordinate system of  
mother volume

# Solids


- **CSG** (Constructed Solid Geometry) solids
  - G4Box, G4Tubs, G4Cons, G4Trd, ...
  - Analogous to simple GEANT3 CSG solids
- **Specific** solids (CSG like)
  - G4Polycone, G4Polyhedra, G4Hype, ...
  - G4TwistedTubs, G4TwistedTrap, ...
- **BREP** (Boundary REPresented) solids
  - G4BREPSolidPolycone, G4BSplineSurface, ...
  - Any order surface
- **Boolean** solids
  - G4UnionSolid, G4SubtractionSolid, ...



# CGS: G4Box


```
G4Box(const G4String& pname, // name
      G4double pX, // half-length in X
      G4double pY, // half-length in Y
      G4double pZ, // half-length in Z);
```

Note the half-length!




# CGS: G4Tubs & G4Cons


```
G4Tubs(const G4String& pname, // name
        G4double pRmin, // inner radius ( $\theta$ )
        G4double pRmax, // outer radius
        G4double pDz, // Z half! length
        G4double pSphi, // starting Phi ( $\theta$ )
        G4double pDphi); // segment angle (twopi)
```




```
G4Cons(const G4String& pname, // name
        G4double pRmin1, // inner radius -pDz
        G4double pRmax1, // outer radius -pDz
        G4double pRmin2, // inner radius +pDz
        G4double pRmax2, // outer radius +pDz
        G4double pDz, // Z half! length
        G4double pSphi, // starting Phi
        G4double pDphi); // segment angle
```




# Other CGS solids




**G4Torus**



**G4Trd**




**G4Trap**




**G4Para**  
(parallelepiped)

**G4Sphere**



**G4Orb**  
(full solid sphere)




Check [Section 4.1.2](#) of Geant4 Application Developers Guide for [all available shapes](#)


# Boolean solids

- Solids can be **combined** using **boolean operations**:
  - **G4UnionSolid**, **G4SubtractionSolid**, **G4IntersectionSolid**
  - Requires: **2 solids**, 1 boolean **operation**, and an (optional) **transformation** for the 2<sup>nd</sup> solid
  - 2<sup>nd</sup> solid is positioned relative to the **coordinate system** of the 1<sup>st</sup> solid
  - Result of boolean operation **becomes a solid** → **re-usable** in a boolean operation
- Solids to be combined can be **either CSG** or **other Boolean solids**
- Note: **tracking cost** for the navigation in a complex Boolean solid is **proportional** to the **number of constituent CSG solids**


G4UnionSolid



G4SubtractionSolid



G4IntersectionSolid





# Boolean solids – an example

```
G4VSolid* box = new G4Box("Box",50*cm,60*cm,40*cm);
G4VSolid* cylinder =
    new G4Tubs("Cylinder",0.,50.*cm,50.*cm,0.,twopi);

G4VSolid* union =
    new G4UnionSolid("Box+Cylinder", box, cylinder);

G4VSolid* subtract =
    new G4SubtractionSolid("Box-Cylinder", box, cylinder,
        0, G4ThreeVector(30.*cm,0.,0.));

G4RotationMatrix* rm = new G4RotationMatrix();
rm->RotateX(30.*deg);
G4VSolid* intersect =
    new G4IntersectionSolid("Box&&Cylinder",
        box, cylinder, rm, G4ThreeVector(0.,0.,0.));
```





# Boolean solid - example

---





# Logical volumes

---


- Contains **all information** of volume **except position**:
  - Shape and dimension (`G4VSolid`)
  - Material, sensitivity, visualization attributes
  - Hierarchy of **daughter** volumes
  - Magnetic field, User limits
- **Physical volumes** of same type **can share** a logical volume.
- The pointers to solid and material **must be not nullptr**

```
G4LogicalVolume(G4VSolid* pSolid,  
                G4Material* pMaterial,  
                const G4String& name,  
                G4FieldManager* pFieldMgr=0,  
                G4VSensitiveDetector* pSDetector=0,  
                G4UserLimits* pULimits=0,  
                G4bool optimise=true);
```


} optional

# Physical volumes

- A **physical volume** is a **positioned instance** of a **logical volume** inside another **logical volume** (the mother volume)
- Placement (**G4PVPPlacement**)
  - it is **one** positioned volume
- Repeated: a volume placed **many times**
  - can represent any number of volumes
  - reduces use of **memory**
  - **G4PVReplica** (= simple repetition)
  - **G4PVParameterised** (= more complex pattern)
    - **G4PVDivision**




*placement*



*repeated*


# Geometry hierarchy

- A volume is **placed** in its **mother volume**
  - **Position and rotation** of the daughter volume is described with respect to the **local coordinate system** of the mother volume
  - The **origin** of the mother's local coordinate system is at the **center** of the mother volume
  - Daughter volumes **cannot protrude** from the mother volume
  - Daughter volumes **cannot overlap**
- The **logical volume** of mother **knows** the daughter volumes it contains
  - It is **uniquely** defined to be their mother volume



# Geometry hierarchy

- One logical volume can be placed **more than once**. One or more volumes can be placed in a mother volume
- The **mother-daughter relationship** is an information of `G4LogicalVolume`
  - If the **mother volume is placed more than once**, all daughters by definition appear in each placed physical volume
- The **world volume** must be a unique physical volume which **fully contains** all other volumes (root volume of the hierarchy)
  - The world volume defines the **global coordinate system**. The **origin of the global coordinate system** is at the center of the world volume
  - **Position of a track** is given with respect to the **global coordinate system**





# G4PVP1acement

---


- Single volume positioned **relatively** to the **mother volume**
  - In a frame **rotated** and **translated** relative to the coordinate system of the **mother volume**
- A **few variants** available:
  - Using **G4Transform3D** to represent the direct rotation and translation of the solid instead of the frame (*alternative constructor*)
  - specifying the mother volume as a **pointer** to its **physical volume** instead of its **logical volume**
- **Four constructors** available
  - **logical** OR **physical** volume as mother
  - **active** OR **passive** transformation of the coordinate system

# G4PVPlacement

## Rotation of mother frame ...

Single volume positioned relatively to the mother volume  
(passive transformation)

```
G4PVPlacement(G4RotationMatrix* pRot,          // rotation of mother frame
              const G4ThreeVector& tlate,      // position in mother frame
              G4LogicalVolume* pCurrentLogical,
              const G4String& pName,
              G4LogicalVolume* pMotherLogical,
              G4bool pMany,                    // not used. Set it to false..
              G4int pCopyNo,                  // unique arbitrary index
              G4bool pSurfChk=false );       // optional overlap check
```




# G4PVPlacement

## Rotation in mother frame ...

Single volume positioned relatively to the mother volume (**active transformation**)


```
G4PVPlacement(G4Transform3D(  
    G4RotationMatrix &pRot,          // rotation in daughter frame  
    const G4ThreeVector &tlate),    // position in mother frame  
    G4LogicalVolume *pDaughterLogical,  
    const G4String &pName,  
    G4LogicalVolume *pMotherLogical,  
    G4bool pMany,                    // not used, set it to false..  
    G4int pCopyNo,                   // unique arbitrary integer  
    G4bool pSurfChk=false );        // optional overlap check
```





# Geometry problems

- Geant4 **does not allow** for **malformed geometries**, neither **protruding** (daughter/mother) not **overlapping** (sisters)
  - The behavior of navigation is **unpredictable** for such cases
- The problem of **detecting overlaps** between volumes is bounded by the complexity of the solid models description
- **Utilities** are provided for detecting wrong positioning
  - **Optional checks** at construction
  - Kernel **run-time commands**
  - **Graphical** tools (DAVID)





# Tools for geometry check

- Constructors of **G4PVPlacement** and **G4PVParameterised** have an optional argument "pSurfChk"

```
G4PVPlacement(G4RotationMatrix* pRot,  
              const G4ThreeVector &tlate,  
              G4LogicalVolume *pDaughterLogical,  
              const G4String &pName,  
              G4LogicalVolume *pMotherLogical,  
              G4bool pMany, G4int pCopyNo,  
              G4bool pSurfChk=false);
```

- If this flag is **true**, **overlap check** is done at the construction
- Some number of points are **randomly sampled** on the surface of creating volume
- This check **requires lots of CPU time**, but it is worth to **try** at least **once**
- **Built-in run-time commands** to activate verification tests for the user geometry:
  - `/geometry/test/run` or `/geometry/test/grid_test`
  - start **verification of geometry** for overlapping regions based on a **standard grid setup**, limited to the first depth level
  - `/geometry/test/recursive_test` for all depth levels (CPU intensive!)



# Regions

---

- A **region** is a **sub-set** of the geometry
- It may have its **specific**
  - Production **thresholds** (cuts)
  - User **limits**
    - Artificial limits affecting to the tracking, e.g. max step length, max number of steps, min kinetic energy left, etc.
  - **Field** manager
- **World** logical volume is recognized as **the default region**. User is **not allowed** to define a region to the world logical volume



Hands on....

---