


Geant4 Interface In Shoe



Geant4

Introduction (i)



- Documentation: <https://geant4.web.cern.ch/docs/>
- Download last version: <https://geant4.web.cern.ch/download/11.3.0.html>
- CMake options (in build folder):
 - `cmake ../geant4-v11.3.0 -DGEANT4_USE_OPENGL_X11=true -DGEANT4_USE_QT*=true -DGEANT4_BUILD_MULTITHREADED=OFF** -DCMAKE_BUILD_TYPE=Debug -DGEANT4_INSTALL_DATA***=ON`

* need to install Qt5 package

** to be compliant with Shoe

*** will download database set in build/data folder

Introduction (ii)


□ Units:

- Default wise:
 - millimeter (mm), nanosecond (ns)
 - Mega electron Volt (MeV)
 - degree Kelvin (kelvin)
 - the amount of substance (mole)
 - radian (radian)
 - steradian (steradian)
- Conversion factors (namespace CLHEP)
 - micrometer, picosecond, ...
 - joule, ...
 - degree,
 - ...

Introduction (iii)

□ Point of entry: RunManager


- Geant4 works through a set of Actions
- Most of what the user can customise need to be registered through the G4RunManager



Geometry in G4 (i)

❑ Volumes:

- Geometry in Geant4 is defined through three levels:
 - The solid volume, which defines the shape and dimensions of the volume.
 - The logical volume, which defines the material, whether the volume is sensitive or not, etc.
 - The physical volume, which positions the volume.




Geometry in G4 (ii)



Shapes:

Examples:

```
G4Box( const G4String& pName,
        G4double pX,
        G4double pY,
        G4double pZ );
```



```
G4Tubs( const G4String& pName,
         G4double pRMin,
         G4double pRMax,
         G4double pDz,
         G4double pSPhi,
         G4double pDPhi );
```



Geant 4

Image sources: geant4.cern.ch

212

Geometry in G4 (iii)

Implementation:

- `runManager->SetUserInitialization( new DetectorConstruction );`

```
class DetectorConstruction : public G4VUserDetectorConstruction
{
public:

    DetectorConstruction();
    ~DetectorConstruction();

public:
    . . .
    G4VPhysicalVolume* Construct();
    . . .
};
```

must inherits from




Need to be implemented



Beam in G4 (i)

□ G4ParticleGun:

- Shouting particles with a given:
 - Type
 - Energy, momentum
 - Polarisation
 - Atomic charge
 - Number of impinging particles
- Shape and position of beam



Beam in G4 (ii)

❑ Implementation:

- runManager->SetUserAction(new PrimaryGeneratorAction);

```
class PrimaryGeneratorAction : public G4VUserPrimaryGeneratorAction
{
public:
    PrimaryGeneratorAction();
    ~PrimaryGeneratorAction();
private:
    G4ParticleGun*          fParticleGun;
    G4GeneralParticleSource* fGeneralParticleSource;

public:
    void GeneratePrimaries(G4Event*);

    . . .
};
```

must inherits from



Need to be implemented



Physics in G4 (i)

☐ PhysicsList:

- Several families of process are present:
 - **Electromagnetic physics**
 - **Ion nuclear interactions**
 - Transport
 - Extra physics processes for gamma and leptons
 - Decay
 - Hadron elastic
 - Hadron inelastic
 - Stopping particles capture processes
 - Photo-leptonic
 - Optic

☐ Electromagnetic Model (i):

- EM processes applied for:
 - Electrons and positrons
 - X-Ray & γ -Ray
 - Muons
 - Charged hadrons
 - Ions

• processes

Energy
Loss

- Multi-scattering
- Bremsstrahlung
- Ionisation
- Annihilation
- Photoelectric effect
- Compton scattering
- Rayleigh scattering
- Gamma conversion
- Pair creation
- Synchrotron radiation
- Cherenkov radiation
- Refraction
- Reflection
- Absorption
- Scintillation
- Fluorescence
- Auger emission

Physics in G4 (ii)

❑ Electromagnetic Model (ii):

- Excerpt of available models


Constructor	Comments	Energies
G4EmStandardPhysics	Default	< 100 TeV
G4EmStandardPhysics_option1	Fast but less precise	< 100 TeV
G4EmStandardPhysics_option2	Experimental	< 100 TeV
G4EmStandardPhysics_option3	Medical and space applications	< 100 TeV
G4EmStandardPhysics_option4	Most precise	< 100 TeV
G4EmLivermore	Opt. 3 + Livermore (γ , e-)	250 eV - 100 GeV
G4EmPenelope	Opt. 3 + Penelope (γ , e-, e+)	100 eV - 1 GeV
G4EmLivermorePolarized	Opt. 3 + Livermore + polarisation (γ)	250 eV - 100 GeV
G4EmDNA	Opt. 3 + DNA	7 eV - 100 MeV
G4EmLowEPPPhysics	Livermore + improved Compton	250 eV - 100 GeV

- More Electromagnetic physics constructors

Physics in G4 (iii)

□ Electromagnetic Model (iii):

- Examples:
 - Energy deposition of protons in water @ 100 MeV




- Comparison stopping power for protons tabled (PSTAR) and simulated

Physics in G4 (iv)

☐ Hadronic and ions Models (i):

- Hadronic model manage (in)-elastic processes hadron with the atomic nucleus (up to 100 TeV)
- Models are more accurate depending on the energy range
- Cross section are computed or loaded independently (need to load data files)
- Several ready-to-use physics lists are provided by the Geant4 developers
- Different models can be used on a same energy range



Physics in G4 (v)

☐ Hadronic and Ion Physics Lists/Models (ii):

- Excerpt of physics lists available

- FTFP_BERT,
- FTFP_BERT_TRV,
- FTFP_BERT_ATL,
- FTFP_BERT_HP,
- FTFQGSP_BERT,
- FTFP_INCLXX,
- FTFP_INCLXX_HP,
- FTF_BIC,
- LBE,
- QBBC,
- QGSP_BERT,
- Shielding,
- ShieldingLEND,
- ShieldingLLXX_HPT,
- Shielding_HPT,
- ShieldingLIQMD_HPT,
- ShieldingM_HPT,
- QGSP_BERT_HP,
- QGSP_BIC,
- QGSP_BIC_HP,
- QGSP_BIC_AllHP,
- QGSP_FTFP_BERT,
- QGSP_INCLXX,
- QGSP_INCLXX_HP,
- QGS_BIC,
- IQMD,
- ShieldingM,
- NuBeam,
- Shielding_HP,

- ShieldingLIQMD_HP,
- ShieldingM_HP,
- FTFP_BERT_HPT,
- FTFP_INCLXX_HPT,
- QGSP_BERT_HPT,
- QGSP_BIC_HPT,
- QGSP_BIC_AllHPT,
- QGSP_INC

- Excerpt of ion models available

- G4IonBinaryCascadePhysics,
- G4IonPhysics,
- G4IonPhysicsXS,
- G4LightIonQMDPhysics,
- G4IonINCLXXPhysics,
- G4IonPhysicsPHP,
- G4IonQMDPhysics.cc

Physics in G4 (vi)



□ Hadronic and ions Models (iii):

- High-energy models (string models)
 - **QGS**: Quark-Gluon String, QCD model, valid between 20 GeV and 1 TeV.
 - **FTF**: Fritiof Fragmentation, an alternative model to QGS, valid between 3 GeV and 1 TeV.
- Cascades:
 - **Bertini**: classical model, widely used for LHC applications, for incident particles: p , n , π , K^+ , K^- , K_L^0 , K_S^0 , Λ , Σ^+ , Σ^- , Ξ^- , Ξ^+ , Ξ^0 , Ω^- , γ , e^- .
 - **BIC**: similar to Bertini, but uses the Pre-Compound model for nuclear de-excitation after the cascade. Incident particles: p , n from 0 to 10 GeV, π from 0 to 1.3 GeV.
The G4BinaryLightIonReaction class contains a binary cascade model for light ions.
 - **INCL++**: Liege intra-nuclear cascade, used in nuclear physics, particularly for spallation studies, valid for p , n , π up to 3 GeV/u.
 - **QMD**: Quantum Molecular Dynamics, applies only to particles heavier than p , n .
- Pre-equilibrium model: G4PrecompoundModel.
- De-excitation model: G4ExcitationHandler.

Physics in G4 (vii)

Hadronic and ions Model (iv):

- Examples:
 - Cross section of ^{11}B production in $(p, ^{12}\text{C})$ reaction



Physics in G4 (viii)

Implementation:

- `runManager->SetUserInitialization(new PhysicsList);`

```
class PhysicsList: public G4VModularPhysicsList
{
public:

    PhysicsList();
    ~PhysicsList();

    virtual void ConstructParticle();
    virtual void ConstructProcess();

    . . .
};
```

must inherits from


Need to be implemented

- Pre-existing physics list initialisation:
 - `runManager->SetUserInitialization(new QGSP_BERT());`
 - `runManager->SetUserInitialization(new QGSP_BIC());`
 - `runManager->SetUserInitialization(new QGSP_INCLXX());`
 - More reference physics lists

Geant4 in Shoe

Folder in Shoe

□ G4Simulation:



- ➔ Dedicated classes in G4Simulation folder, same structure as for Libraries folder
- ➔ Activate at cmake level: `cmake -DGeant4_DIR=$G4_BUILD11 /path/to/foot/src`
(need Geant4 version $\geq 11.2.0$)

Geometry in Shoe (i)


□ Classes:

- TCGtargetConstructor: construct target geometry with TAGparGeo interface
- TC*geometryConstructor: construct ST, BM, VT, IT, EM*, MSD, TW and CA geometry with TA*parGeo interfaces (*EM = Dipole)
- TCFOgeometryConstructor: construct and placed detectors/target with TAGgeoTrafo interface.

□ Interfaces with Shoe:

- Geometry files call via the TAGcampaignManager interface
- Detectors switch off/on respect to TAGrecoManager interface
- All configuration and geometry files copy in G4Simulation folder (build)

- ➔ Still some corrections in BM and TW geometry
- ➔ Need to add passive materials (boxes)



Geometry in Shoe (ii)

Implementation:

- Example: TCVTgeometryConstructor

```
class TCVTgeometryConstructor : public TCGbaseConstructor
{
public:
    TCVTgeometryConstructor(TAVTbaseParGeo* pParGeo);
    virtual ~TCVTgeometryConstructor();

    // Method in which the physical volume is constructed
    virtual G4LogicalVolume* Construct();
    . . .
};
```

Interface with shoe geometry




Need to be implemented



Magnetic Field in Shoe

Classes:

- TCEMgeometryConstructor: construct dipole geometry with TADlparGeo interface
- TCEMfield: get back the field map values with TADlgeoField interface
- TCEMfieldSetup: set propagation model (helix, Euler, Runge-Kutta, etc...)
- Printout info when including dipoles:



```
Info in <TCEMgeometryConstructor::Construct()>: Construct Magnets
Info in <TADlgeoField::TADlgeoField()>: Going to open ./data/MagneticMap_2023.table
Info in <TCEMfieldSetup::SetStepper()>: G4ClassicalRK4 (default) is called
Info in <TCEMfieldSetup::CreateStepperAndChordFinder()>: The minimal step is equal to 1.000000 mm
```

Beam in Shoe

Classes:

- TCGprimaryGeneratorAction: interface with TAGparGeo class

Implementation:

```
class TCGprimaryGeneratorAction : public G4VUserPrimaryGeneratorAction
{
public:
    TCGprimaryGeneratorAction(TAGparGeo* pParGeo);
    ~TCGprimaryGeneratorAction();

public:
    // Generate primaries
    void GeneratePrimaries(G4Event* anEvent);

private:
    G4ParticleGun* fParticleGun;          ///< Particle gun
    TAGparGeo*     fpParGeo;              ///< Geometry parameters for beam
    Bool_t         fHasPartDefined;      ///< Flag for defined particle
};
```

Interface with shoe geometry

Need to be implemented

Physics in Shoe (i)

TCGbasePhysics:

- Standard progresses: ion/hadron elastic, decay and EM

```
TCGbasePhysics::TCGbasePhysics()  
{  
    G4VModularPhysicsList(),  
    . . .  
    {  
        // Ion Elastic scattering  
        fIonElastic = new G4IonElasticPhysics(0);  
        RegisterPhysics(fIonElastic);  
        . . .  
        // Particle decays  
        fDecay = new G4DecayPhysics();  
        fRadioactiveDecay = new G4RadioactiveDecayPhysics(0);  
        RegisterPhysics(fDecay);  
        RegisterPhysics(fRadioactiveDecay);  
        . . .  
        // EM  
        fExtraEmPhysics = new G4EmExtraPhysics(0);  
        RegisterPhysics(fExtraEmPhysics);  
        fElectromagnetic = new G4EmStandardPhysics_option3(0);  
        RegisterPhysics(fElectromagnetic);  
        . . .  
        // Hadron elastic physics  
        fHadronElastic = new G4HadronElasticPhysicsHP(0);  
        RegisterPhysics(fHadronElastic);  
    }  
}
```

Physics in Shoe (ii)

□ TCGphysicsINCLXX:

- Related physics processes for ion/hadron inelastic and stopping

```
TCGphysicsINCLXX::TCGphysicsINCLXX()  
{  
    : TCGbasePhysics()  
    {  
        // Stopping Physics  
        fStoppingPhysics = new G4StoppingPhysicsWithINCLXX(0) ;  
        RegisterPhysics(fStoppingPhysics);  
        . . .  
        // Ion Inelastic physics  
        fIonInelastic = new G4IonINCLXXPhysics(0) ;  
        RegisterPhysics(fIonInelastic);  
        . . .  
        // Hadron Inelastic physics  
        fHadronInelastic = new G4HadronPhysicsINCLXX(0) ;  
        RegisterPhysics(fHadronInelastic);  
        . . .  
    }  
}
```

Physics in Shoe (iii)

TCGphysicsQMD:

- Related physics processes for ion/hadron inelastic and stopping (flag for heavy ion model)

```
TCGphysicsQMD::TCGphysicsQMD(Bool_t heavy)
:   TCGbasePhysics()
{
    // Stopping Physics
    fStoppingPhysics = new G4StoppingPhysics(0);
    RegisterPhysics(fStoppingPhysics);
    . . .
    // Ion Inelastic physics
    fIonInelastic = 0x0;
    if (heavy) {
        fIonInelastic = new G4IonQMDPhysics(0);
    . . .
    } else {
        fIonInelastic = new G4LightIonQMDPhysics(0);
    . . .
    }
    RegisterPhysics(fIonInelastic);

    // Hadron Inelastic physics
    fHadronInelastic = new G4HadronPhysicsQGSP_BIC_HP(0);
    RegisterPhysics(fHadronInelastic);
    . . .
}
```

Physics in Shoe (iv)

TCGphysicsBIC:

- Related physics processes for ion/hadron inelastic and stopping (flag for HP*)

```
TCGphysicsBIC::TCGphysicsBIC(Bool_t hp)
:   TCGbasePhysics()
{
    // Stopping Physics
    fStoppingPhysics = new G4StoppingPhysicsFritiofWithBinaryCascade(0);
    RegisterPhysics(fStoppingPhysics);
    . . .
    // Ion Inelastic physics
    fIonInelastic = 0x0;
    if (hp) {
        fIonInelastic = new G4IonPhysicsPHP(0);
    } else {
        fIonInelastic = new G4IonPhysics(0);
    }
    RegisterPhysics(fIonInelastic);
    . . .
    // Hadron Inelastic physics
    fHadronInelastic = 0x0;
    if (hp) {
        fHadronInelastic = new G4HadronPhysicsQGSP_BIC_AllHP(0);
    } else {
        fHadronInelastic = new G4HadronPhysicsQGSP_BIC(0);
    }
    RegisterPhysics(fHadronInelastic);
    . . .
}
```



* Need an additional database set (TANDLE)

Physics in Shoe (v)

□ EM cuts:

- Default wise cuts put on e^+ , e^- and γ tracking

```
if (cutEM) {  
  physics->SetCutValue(1.*CLHEP::m, "gamma");  
  physics->SetCutValue(1.*CLHEP::m, "e-");  
  physics->SetCutValue(1.*CLHEP::m, "e+");  
}
```



Physics in Shoe (vi)

□ Main class: TAGsimulation

```
#if G4VERSION_NUMBER < 1102
    printf("Geant4 v11.01 and below not supported");
    exit(0);
#else
    if (physListName == "bic")
        physics = new TCGphysicsBIC();
    else if (physListName == "bichp")
        physics = new TCGphysicsBIC(true);
    else if (physListName == "incl")
        physics = new TCGphysicsINCLXX();
    else if (physListName == "qmd")
        physics = new TCGphysicsQMD();
    else if (physListName == "qmdhi")
        physics = new TCGphysicsQMD(true);
    else
        printf("\n\n No physics list defined !!\n\n");
#endif
```

- Pre-implemented physics list
 - BIC (HP)
 - QMD (HI)
 - INCL

Event Action

❑ Class:

- TCFOeventAction: fill the TAMCnTuHit container via the help of TAMCevent

❑ Implementation:

```
class TCFOeventAction : public TCFObaseEventAction
{
public:
    TCFOeventAction(TCFOrunAction* runAction,
                    TCGbaseGeometryConstructor* hitGeomConstructor);
    ~TCFOeventAction();

public:
    // Begin event action
    void EndOfEventAction(const G4Event*);
    // Collect hits
    void Collect(const G4Event* evt);

private:
    // Fill track (particle) containers
    void FillTrack();
    // Fill shoe hits from G4 hits
    void FillHits(TAMCevent* mcHit, TCGmcHit* hit);
```



Fill the shoe container from hit collection
from sensitive volumes

Tracking Action

❑ Class:


- TCFOTrackingAction: fill the TAMCntuPart container via the help of TAMCevent

❑ Implementation:

```
class TCFOTrackingAction : public G4UserTrackingAction
{
private :
    TCFObaseEventAction* fEventAction;          ///< event action

public :
    TCFOTrackingAction(TCFObaseEventAction* aEventAction);
    ~TCFOTrackingAction();

    // Pre-tracking action
    void PreUserTrackingAction(const G4Track*);
    // Post-tracking action
    void PostUserTrackingAction(const G4Track*);
};
```



Fill at the end of tracking

Executable

❑ Command line:

- Default with mandatory options:

TAGsimulation -**exp** CNAO23PS_MC -**run** 200

- Additional options:

-**out** fileName : output root file name (default wise: “exp_run.root”)

-**nev** number : number of events to process (otherwise take the one in TAGparGeo interface)

-**frag** : option to record only fragmented events

-**phys** [bic(hp) qmd(hi) incl] : option to choose a given physics list (default wise: incl)


-**seed** number : option to choose a given seed

-**nocuts** : option to remove EM cuts

-**i** : activate the interactive mode in Geant4

Outputs


- Geant4 in SHOE creates an output rootfile containing a TTree (EventTree):
 - With the TAMCntuPart, TAMCntuHit, TAMCntuEvent and TAMCntuRegion* containers:




*Only Sensitive regions saved

Conclusions

- Geant4 in SHOE (with some corrections) is able to produce MC data



- ➡ Still some debugging in geometry (e.g.: BM fix with the help of Yun)



End

Backup