ALCOR simulations

F. Cossio, G. Dellacasa, C. Ferrero

14.11.2025

T_{fine} = TDC output = TDC conversion time


Select time-inverted data outputs $\rightarrow T_{coarse}[i] < T_{coarse}[i-1]$ (14% events)

Plot T_{fine}[i] vs T_{fine}[i-1]

Almost all points have:

$$T_{fine}[i] > T_{fine}[i-1]$$

 Longer conversion time explains time-inverted data outputs



T_{fine} = TDC output = TDC conversion time

Select time-inverted data outputs $\rightarrow T_{coarse}[i] < T_{coarse}[i-1]$ (14% events)

Plot $T_{fine}[i]$ vs $T_{fine}[i-1]$

Check rare cases when:

$$T_{fine}[i] < T_{fine}[i-1]$$


- ➤ Pixel 0-1-2 have more entries w.r.t. pixel 5-6-7
- ➤ This is due to pixel

 readout priority when

 more than one pixel has

 one data ready to be

 transmitted to the EoC



T_{fine} = TDC output = TDC conversion time


Select time-inverted data outputs $\rightarrow T_{coarse}[i] < T_{coarse}[i-1]$ (14% events)


Plot $T_{fine}[i]$ vs $T_{fine}[i-1]$

Check rare cases when:

$$T_{fine}[i] < T_{fine}[i-1]$$

- ➤ Pixel 0-1-2 have more entries w.r.t. pixel 5-6-7
- This is due to pixel readout priority when more than one pixel has one data ready to be transmitted to the EoC






 T_{fine} = TDC output = TDC conversion time


Select time-inverted data outputs $\rightarrow T_{coarse}[i] < T_{coarse}[i-1]$ (14% events)

Plot $T_{\text{coarse diff}} = T_{\text{coarse}}[i] - T_{\text{coarse}}[i-1]$

MAX negative difference is about 128 (= MAX TDC conversion time)

Still some points have: $abs(T_{coarse\ diff}) > 128$






Summary


Simulation settings:

- LE mode
- DCR = 16 MHz/column = 2 MHz/ch → real DCR = 1.25 MHz/ch
- PHY rate = 1 MHz/column
- Shutter width = 2.5 ns
- ➤ In this simulation we have 14% events with time-inverted data output
- Same simulation in SR mode gives 21% events


New simulation in SR mode with:

- DCR = 4 MHz/column = 500 kHz/ch → real DCR = 450 kHz/ch
- PHY rate = 100 kHz/column
- Shutter width = 7.5 ns





TCoarse_diff per PixelID (Col 0)



TCoarse_diff_TFineprev>TFine per PixelID (Col 0)

