
n_TOF Irradiation Updates


Sara Rabaglia - 23/10/2025

EAR1

CERN


3 Experimental area:






3 Experimental area:

EAR1







3 Experimental area:

EAR1


• EAR2






3 Experimental area:


- EAR1
- EAR2
- NEAR








2 treated samples: C1 and C7



2 treated samples: C1 and C7

2 non-treated samples: D9 and B1




2 treated samples: C1 and C7

2 non-treated samples: D9 and B1

1 commercial pure quartz powder (Goodfellow)






Samples preparation

1. Powder weighed and pressed into a PEEK capsule.

2. Capsule closed with a mylar foil and kapton tape.

3. In front of each capsule, a gold foil was fixed with masking tape









EAR1


- 2 steps of irradiation —> 6 samples (3+3)
- Parasitic irradiation: escape line
- 1° irradiation:
 - Fission Collimator
 - 10/09/2025 29/09/2025
- 2° irradiation:
 - Capture Collimator
 - 29/09/2025 ...

• Samples:

$$- m = 10 g$$

- D = 30 mm, h = 13 mm


- C7, D9, GF





EAR2

- 1 irradiation —> 2 samples
- Dedicated irradiation
- 1° irradiation:
 - 17/10/2025 27/10/2025
- Samples:
 - m = 4.5 g
 - D = 20 mm, h = 10 mm
 - C1 and D9



NEAR

- 2 steps of irradiation —> 6 samples
 (3+3) with and without filter (B₄C)
- Dedicate irradiation
- 1° irradiation (without filter):
 - 16/10/2025 22/10/2025
- 2° irradiation (with filter):
 - 22/10/2025 29/10/2025

• Samples:

- m = 1 g
- D = 13 mm, h = 6 mm
- C1, D9, GF





Why Gold?

Pure stable gold (99.9% ¹⁹⁷Au)

Activation of gold irradiated with a neutron flux is well known.

Reaction of interest: 197 Au(n,2n) 196 Au -> threshold = 8 MeV.

¹⁹⁶Au half-life ∼6 days


Measuring the activity after irradiation, it's possible to calculate the flux above 8 MeV that irradiates the corresponding sample.

Normalization of the flux received by each sample






Gold activity: Ge-detector




Soon the gold activity measurement will be ready.





Soon the gold activity measurement will be ready.

All the irradiated samples are stored, ready to be shipped to CIRCE for AMS.



Electrostatic Analyzer

E/q= 5.1 MeV r= 2.54 m

Soon the gold activity measurement will be ready.

All the irradiated samples are stored, ready to be shipped to CIRCE for AMS.

	cm	cm^2		cm					n/cm^2/h	1 giorno
PESO g	RAGGIO	Area	molecole/barn	spessore	density				8.5	204
10	3	28.2743339	0.003544841	0.306965509	1.152173913					
Formula	Peso molare			reaction/bunch		protons	bunch	neutrons	Reactions	incertezza
SiO2	60.083		EAR1	1.01E+00		4.00E+18	5.71E+05	6.22E+10	5.79E+05	2.89E+04
			EAR2	6.27E+00		4.00E+18	5.71E+05	1.30E+12	3.58E+06	1.79E+05
Si	28.085		NEAR	1.16E+04		6.00E+17	8.57E+04	3.32E+12	9.97E+08	4.99E+07
0	15.999								2.49E+08	
Sigma (b)	0.003									
	Alberto M	MISURATO	BIF	BIF fission	MIchi BIF					
flux EAR1 (n/bunch)	1.09E+05	1.36E+05	7.00E-01		7.00E-01					
flux EAR2	2.27E+06	2.00E+06	2.60E-01		2.00E-01					
flux NEAR (n/cm^2/pp)	3.87E+07		3.56E+07		3.56E+07					
Contenuto MAX	1.00E+06	Be							5.79E+03	76.0604
	4.00E+06	Al								
					BIF					
						r=1 cm	r=1.5cm			
				PPAC	EAR1 capture	0.83	0.97	measured		
oroduct	ion r	ata		TC rescaled	EAR1 NEL	0.51	0.78	simulated		
product		ait		PPAC	EAR2 capture	0.34	0.61	measured		
				TC rescaled	EAR2 top pipe	0.13	0.26	simulated		

Theoretical framework to calculate production rate and integrated cross section is under development and almost ready.



Soon the gold activity measurement will be ready.

All the irradiated samples are stored, ready to be shipped to CIRCE for AMS.

Theoretical framework to calculate production rate and integrated cross section is under development and almost ready.

Irradiation continues!



