


Test beam results of MCP in “ionisation mode” for detection of single charged particles and EM showers



paolo.meridiani@roma1.infn.it

Università di Roma "La Sapienza" & INFN Roma
 D. del Re, G. D'Imperio, M. Diemoz, S. Gelli, C. Jorda Lope, G. Organtini, L. Pernie', S. Rahatlou, F. Santanastasio

INFN Roma

F. Cavallari, P. Meridiani, R. Paramatti, C. Rovelli

Università di Milano Bicocca & INFN Milano Bicocca

L. Brianza, R. Gerosa, A. Ghezzi, C. Gotti, P. Govoni, A. Martelli, B. Marzocchi, S. Pigazzini, T. Tabarelli de Fatis


BINP (Novosibirsk)

Mikhail Yu. Barnyakov, Alexander Yu. Barnyakov

MCP as MIP/EM shower TOF detector


PMT-MCP mode

- ➔ High efficiency & excellent time resolution (<20ps)
- ➔ Issues for colliders: lifetime & radiation hardness (photocathode)



i-MCP mode

- ➔ Secondary emission in the MCP, no photocathode
- ➔ more radiation hard, improved lifetime, robust/easier assembly




Pile-up @ future hadron colliders

High instantaneous luminosity $>10^{34} \text{ cm}^{-2}\text{s}^{-1}$ in pp colliders is achieved at a cost of large number of collisions for BX.

e.g.: HL-LHC (2024): 140 PU. Time spread ~200ps

Idea: use time-of-flight information in calorimeters to aid the full event reconstruction

- ➔ **pile-up mitigation**: remove energy deposits in calorimeters not associated to the hard interaction (e.g. pile-up jets identification, improve MET resolution...)
- ➔ **triangulate high energy photons** from Higgs decay to production vertex



<50ps TOF resolution is needed to get rejection in forward EM calorimeter of pile-up photons


i-MCP test beam setup


1 PMT-MCP: trigger and time reference (15ps resolution)

Different configurations tested in

i-MCP mode:


- ➔ 2 MCP layers (d/L=1:40) chevron
- ➔ 2 MCP layers (d/L=1:40), surface chemically treated to enhance SEE, chevron
- ➔ 3 MCP layers (d/L=1:40) Z-stack





Test beam results of MCP in "ionisation mode" for detection of single charged particles and EM showers


Single charged particle results



PMT-MCP mode:
100% efficiency

Z-stack & enhanced SEE i-MCP mode:
~ 70% efficiency


20% improvement over standard chevron configuration



$\sigma(t_{TRIG}-t_{MCP}) \sim 40$ ps for Z-stack & enhanced SEE:


35ps resolution on single charged particle for a single detector

EM shower results



0-5 X_0 in front of i-MCP with configurable lead absorber

100% efficiency for EM showers after 2-3 X_0



$\sigma(t_{TRIG}-t_{MCP}) \sim 30$ ps for showers:

25ps resolution for a single EM shower