



DC Proto I instrumentation & Cluster Counting Studies

G. Felici



Front-End Electronics R&D (2009)

- Chamber prototype instrumentation (KLOE DC FEE)

- Cluster counting feasibility study
 - local derivative method
 - oscilloscope acquisition

- RO architecture
 - BaBar "like"
 - Cluster counting option



Proto I Instrumentation

24 channels Preamplification/Amplification/Discrimination



Analog Outputs



Test Inputs

V_{TH} set

Digital outputs



Pre I/O







VTX main features


- Preamplifier type: Single ended common emitter, three stage inverting
- Channels/chip: 6 (independently powered sections of 4 and 2 channels)
- Power supply: 4V
- Inputs: One signal and one ground per channel
- Quiescent input voltage: 0.7V
- Input impedance: 130 ohms
- Outputs: One per channel, single ended. External pulldown to negative voltage required.
- Quiescent output voltage: 1.0V
- Output impedance: 43 ohms
- Impulse gain: 1.0 mv/fc (with a capacitively coupled 43 ohm load)
- Impulse risetime (10-90%): 5 ns
- Impulse falltime (90-10%): 16 ns
- Dynamic range: -400 fc to +20 fc inputs, linear to within 3% at the maximum output (1 ma output pulldown current)
- Power dissipation: 10 mw/channel (1 ma output pulldown current)
- Input noise: 860 electrons + 47 e/pf (100 MHz bandwidth)
- Crosstalk: <0.5% between any two channels

Cluster Counting (Local Derivative Method)



Cluster Counting – Test Bench



Cluster Counting – Measurement Setup (to be implemented)



- Gain = 10mV/ μ A
- tr = 4 ns
- ENC < 1000 erms



VME Scaler

- Double Pulse Resolution : 10 ns
- Input Signal Delay : adjustable (up to 1 μ s)
- Minimum Input Signal Width : 5 ns

Conclusion & Requirements

- Chamber prototype instrumentation (KLOE DC FEE) → Setup completed within October
- Cluster counting feasibility study → Setup completed within November
 - local derivative method
 - oscilloscope acquisition
- RO architecture
 - BaBar “like” (Cluster counting option ?)

To start the work on the RO architecture some information about the foreseen working conditions are required :

- Background rate
- Trigger rate (Lev 1 & 2)
- Power Dissipation
- Material Budget (DC end plates)